



105 Bonnie Drive  
Butler, PA 16002  
724-283-4681  
724-283-5939 (fax)  
www.bwieagle.com

## PRODUCT INFORMATION BULLETIN

### AIR-EAGLE® SR PLUS 2.4 GHz RF Transceiver MODEL 36-40100-AC

#### DESCRIPTION

The Air-Eagle SR RF TRANSCEIVER is a single I/O unit designed to transmit and receive unique signals from an identical unit located up to 600 feet away. This model comes equipped with a single dry contact input and an SPDT relay output. This allows the user to not only transmit information out, but receive a confirming signal back that the operation was performed. The Air-Eagle SR TRX is user-programmable for up to eight network frequencies to allow multiple transceivers to operate simultaneously in the same area and utilizes spread-spectrum technology and provides the utmost security and reliability even in the noisiest RF environments.

#### APPROVALS

|                     |               |
|---------------------|---------------|
| United States (FCC) | OUR-XBEEPRO   |
| Canada (IC)         | 4214A-XBEEPRO |
| Europe (CE)         | ETSI          |

#### APPLICATIONS

Doors, gates, barriers, tail gates, electrically controlled hydraulic valves, propane shut off controls, winches, anchor lifts, lights, sprinkling systems, movie screens, curtains, news weather screens, alarm systems, skeet throwers, saw mill applications, grain or aggregate chutes, conveyor belts, boat lifts, and more.

#### INSTALLATION

DISCONNECT AC Power from all equipment before installation.

1. Mount the Air-Eagle SR TRANSCEIVER in a convenient location.
2. Install wiring to contact input terminal strip
3. Install antenna. The unit has an antenna connector located on the right side on the enclosure. Attach the supplied portable antenna to this connector.
4. Connect AC power to the proper terminals in your control circuit.


#### TERMINAL STRIP WIRING

| TER 3<br>DRY CONTACT INPUT |           | TER 2<br>RELAY OUTPUT |            | TER 1<br>AC/DC POWER INPUT |                  |
|----------------------------|-----------|-----------------------|------------|----------------------------|------------------|
| 1                          | Input 1 C | 1                     | N/O        | 1                          | 120VAC (Neutral) |
| 2                          | Input 1   | 2                     | C (common) | 2                          | 120VAC (Hot)     |
|                            |           | 3                     | N/C        | 3                          | Ground           |



Dimensions (with mounting plate) 7.07L x 3.57W x 1.62H

#### CONTROLS AND INDICATORS



|              |                                                                |
|--------------|----------------------------------------------------------------|
| Power – LED1 | Illuminates green when unit is powered                         |
| TX – LED2    | Illuminates red when unit is transmitting                      |
| Relay – LED3 | Illuminates green when relay is energized                      |
| RF1          | RF module that sends data to the remote receiver               |
| SEL1         | Seven dip switches for selecting options and network frequency |
| TER3         | Dry contact input                                              |
| TER2         | Relay output                                                   |
| TER1         | Power Input                                                    |

# AIR-EAGLE® SR PLUS

## 2.4 GHz RF Transceiver

### MODEL 36-40100-AC

## RELAY & FREQUENCY SET-UP

The unit is shipped from the factory with SEL1 switches in the open positions. The relay will operate as maintained momentary and unit is receiving commands on frequency one. If you wish to change these default settings, follow the instructions on the table below.

- 1) Remove power from unit
- 2) Remove top cover.
- 3) Select desired relay operation and/or network frequency using table below.
- 4) Reattach cover and apply power.
- 5) Programming is now complete.

### RELAY CONFIGURATION

|                 | Relay Operation     | SW1    | SW1    |
|-----------------|---------------------|--------|--------|
| SEL1<br>(SW1-2) | Momentary (default) | OPEN   | OPEN   |
|                 | Toggle/Latch        | CLOSED | OPEN   |
|                 | Latching            | OPEN   | CLOSED |

### OPTIONS

|       |                                 |                       |
|-------|---------------------------------|-----------------------|
| SW3   | Vibrating Feedback Off          | Vibrating Feedback On |
| SW4** | Repeater Function Off (default) | Repeater Function On  |

**Maintained Momentary** – Relay mimics button or input – when depressed or closed, relay will be energized; when released, relay de-energizes

**Toggle/Latch** – Relay changes (and holds) its state each time the corresponding button or input is depressed or closed.

**Latching** – Relay requires two buttons or inputs for operation – momentary press of 1<sup>st</sup> button energizes relay; momentary press of 2<sup>nd</sup> button de-energizes relay

\*\* Enable SW4 Repeater Function in ONLY one Receiver per System

### FREQUENCY SET-UP

|                 | Network Frequency | SW5    | SW6    | SW7    |
|-----------------|-------------------|--------|--------|--------|
| SEL1<br>(SW5-7) | 1 (default)       | OPEN   | OPEN   | OPEN   |
|                 | 2                 | CLOSED | OPEN   | OPEN   |
|                 | 3                 | OPEN   | CLOSED | OPEN   |
|                 | 4                 | CLOSED | CLOSED | OPEN   |
|                 | 5                 | OPEN   | OPEN   | CLOSED |
|                 | 6                 | CLOSED | OPEN   | CLOSED |
|                 | 7                 | OPEN   | CLOSED | CLOSED |
|                 | 8                 | CLOSED | CLOSED | CLOSED |

## FACTORY PROGRAMMED CHANNEL OPTIONS


The 36-40100 can be factory programmed to operate on separate channels for use with multi I/O transceivers. The default is channel 1, but if you'd like your unit to transmit and receive different channel information, use the following part numbers for ordering:

|                  |                               |
|------------------|-------------------------------|
| Model 36-40100-2 | Will TX and RX Channel 2 info |
| Model 36-40100-3 | Will TX and RX Channel 3 info |
| Model 36-40100-4 | Will TX and RX Channel 4 info |
| Model 36-40100-5 | Will TX and RX Channel 5 info |
| Model 36-40100-6 | Will TX and RX Channel 6 info |
| Model 36-40100-7 | Will TX and RX Channel 7 info |
| Model 36-40100-8 | Will TX and RX Channel 8 info |
| etc...           |                               |

## SPECIFICATIONS

|                         |                                     |
|-------------------------|-------------------------------------|
| AC Input                | 110-240 VAC, 5 W, 50/60 Hz          |
| Transmitter Frequency   | 2.4 GHz Spread Spectrum             |
| Transmit Data           | Dry Contact Input                   |
| RF Output Power         | 60 mW                               |
| Transmit Range          | Approximately 600 Feet              |
| Transmitter Frequencies | 8 Independent Network Frequencies   |
| Relay Contact           | SPDT 5 amp @ 120 VAC or 30VDC       |
| Antenna Connection      | TNC Female Connector                |
| Operating Temperature   | -40° F to +185° F                   |
| Enclosure               | Polycarbonate NEMA 4, 12, 13 – IP66 |
| Weight                  | Approx 2 lbs.                       |

## DIMENSIONS



## REPLACEMENT PARTS & ACCESSORIES

|                                                                                                                                                                 |                                |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|
| PC Board (Main)                                                                                                                                                 | 36-40102-AC                    |
| Standard Antenna (Included):                                                                                                                                    |                                |
| 2.4GHz TNC Portable Antenna (For distances up to 600 feet*)                                                                                                     | 49-1201                        |
| Optional Antennas and Accessories –<br>Used to increase range in both non line of sight and line of sight applications. - Contact BWI Eagle for recommendations |                                |
| 2.4GHz Thru-Hole Mount Mobile Antenna                                                                                                                           | 49-2201                        |
| 2.4GHz Magnetic Mount Mobile Antenna                                                                                                                            | 49-2202                        |
| 2.4GHz Omni Directional Antenna                                                                                                                                 | 49-3201                        |
| 2.4GHz 13dB Yagi Antenna                                                                                                                                        | 49-3202                        |
| Flex Coax Cable w/Connectors – Connects external antenna(s) to base unit(s).                                                                                    | 49-4000-XX<br>(XX = # of Feet) |
| 2 Ft. Bulkhead Assembly (Used when mounting receive inside another enclosure)                                                                                   | 49-5004-2-ISO                  |
| * = Line of Sight                                                                                                                                               |                                |

# AIR-EAGLE® SR PLUS

2.4 GHz RF Transceiver

**MODEL 36-40100-AC**

## LIMITED WARRANTY STATEMENT

BWI Eagle Inc. warrants the Air-Eagle Remote Control System, if properly used and installed, will be free from defects in material and workmanship for a period of 1 year after date of purchase. Said warranty to include the repair or replacement of defective equipment. This warranty does not cover damage due to external causes, including accident, problems with electrical power, usage not in accordance with product instructions, misuse, neglect, alteration, repair, improper installation, or improper testing. This limited warranty, and any implied warranties that may exist under state law, apply only to the original purchaser of the equipment, and last only for as long as such purchaser continues to own the equipment. This warranty replaces all other warranties, express or implied including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. BWI Eagle makes no express warranties beyond those stated here. BWI disclaims without limitation, implied warranties of merchantability and fitness for a particular purpose. Some jurisdictions do not allow the exclusion of implied warranties so this limitation may not apply to you. To obtain warranty service, contact BWI Eagle for a return material authorization. When returning equipment to BWI Eagle, the customer assumes the risk of damage or loss during shipping and is responsible for the shipping costs incurred.

---

DOCUMENT DATE: 04/23/19 / PRODUCT REV. 3

---



105 Bonnie Drive  
Butler, PA 16002  
(724) 283-4681  
Fax (724) 283-5939  
[www.bwieagle.com](http://www.bwieagle.com)



105 Bonnie Drive  
Butler, PA 16002  
724-283-4681  
724-283-5939 (fax)  
www.bwieagle.com


# INPUT/OUTPUT WIRING

## 1-Input Transmitter / 1-Relay Receiver

### Dry Contact Input Wiring - Standard

#### Standard wiring of a dry contact input transmitter

Shorting together the contacts of the respective channel will cause it to transmit. This can be done with any type of manual or automatic switch.




### Relay Output Wiring

Receiver outputs are dry relay contacts, like an SPDT switch. When the relay is in a de-energized state, the N/C (normally closed) contact is connected to C (common). When the relay is energized the N/O (normally open) contact is connected to C (common).




### Relay Output Wiring - Normally Open Application with Externally Supplied Voltage



#### Internal Relay - Loads Less Than 5 Amps

Loads up to 5 Amps may be wired directly to the internal relays. Wiring to the N/O contact will cause the load to turn on when the relay is energized (the load is on when the relay is on). Wiring to the N/C contact will cause the load to turn on when the relay is de-energized (the load is on when the relay is off). AC or DC voltages can be switched through the relay.



#### External Relay - Loads Over 5 Amps

Loads over 5 Amps must use an external high current relay. Diagram shows how to turn on the relay using the lower current internal relay of the receiver. AC or DC voltages can be switched through the relay. Note: A protection diode for DC coils or an MOV for AC coils is recommended to reduce inductive EMI noise.